BAKON.COM

















Ø

LESS



Through energy-saving measures, such as dimensioning of electrical power and – where possible – use of recyclable materials, BAKON commits to dealing responsibly with the environment.



BAKON

0

•••••

- Innovation and **Experience Center** Amundsenweg 29a 4462 GP Goes The Netherlands
- Manufacturing facility Stanleyweg 1 4462 GN Goes The Netherlands
- +31 (0)113 244 330 🛚 info@bakon.com
- bakon.com









BD3 DEPOSITING MACHINE

BAKON designs and manufactures standardized and customized depositing, spraying and cutting machines as well as production lines for efficient and high-volume processing of pastry products. BAKON stands for advanced technology and reliability.

The BD3 is a very compact, fast, accurate and flexible depositing machine. This table top depositing machine has a cylinder to take care of depositing volumes between 10 to 550 ml.

The BD3 is a very compact, fast, accurate and flexible depositing machine. This table top depositing machine has a cylinder to take care of depositing volumes between 10 to 550 ml.

Cleaning is fast and simple; it takes less than a minute and no tools to dismantle the depositor. All parts are dishwasher proof.

- Compact, table top size.
- Depositing volume of 10 to 550 ml.
- Hopper capacity of 25 liters. - Quick product change.
- Operating pressure of 4 bar.

- Air consumption at 60 strokes per minute is 70 liter.
- Very fast to (dis)assemble without tools. -All to be cleaned parts are dishwasher proof.

Capacity: medium

**

2


₿

The BD3 DEPOSITOR is available as stand-alone.

Batter, mousses, (whipped) cream, custard, fruit filling with pieces, soups, salads, mashed potatoes, ready-made meals, marinades, pasta sauces, etc. We underline the importance of understanding your product, ingredients and process in configuring your solution. BAKON will look together with you to increase your productivity.

[•] We are happy to test your ingredients.













Dosing speed | The dosing speed can easily be adjusted by means of a rotary knob.



Dosing volume | The dosing volume is manually set and indicated on the scale



Get to know all our depositing solutions